INSTALLATION MANUAL




Step 1



Determine the location of the Speed hump and sweep the surface clean of debris / dust. Use chalk to mark the center lines (parallel and perpendicular to the direction of the street) and border lines on the surface.

Step 2



Assemble and position the units, starting from the center line (parallel to the direction of the street).

Note: Make sure the units are tight and well aligned before moving on to step 3.

Step 3



Drill 12MM diameter holes into the surface, through the existing holes of the placed units. The holes should be 120-140MM deep in order to accommodate the plastic shields that are 100MM long.

Step 4



Make sure the holes are clear of dust and debris before installing the shields. After each hole is drilled, insert a plastic shield in order to keep the units from shifting.

Note: (A portable blower is useful for this purpose)

Step 5



Insert the bolts and steel washers into the product installation holes and tighten every element.

Maintenance

Speed Hump require minimal maintenance. Periodically inspect the bolts and tighten if necessary.

Unimat Industries, LLC 6980 NW 43rd Street, Miami, FL 33166